# Inverted Pendulum Project

Andrew Mascillaro, Nolan Flynn

### Base Model

The base model for Rocky is an inverted pendulum. It is approximated to a long rod of an effective length  $l_{eff}$ . Also, it has two wheels and an axle at the bottom, which are connected to a motor. The motor is controlled by a control system, which takes in the angle (displacement) of the system and outputs a rotational force on the axle, preferably one that helps the inverted pendulum stabilize itself.

We have two main measures for determining the success of our control system.

- 1. Rocky should not fall if given a disturbance of  $30^{\circ}$  or less. This disturbance would have a magnitude of  $< 30^{\circ}$  degrees and last about 0.1 seconds. We believe this is an achievable goal and should protect Rocky from most common disturbances in the environment.
- 2. Rocky should stabilize to an oscillation no greater than  $1^{\circ}$  2 seconds after a disturbance. This would prove that Rocky can effectively reach a steady state in a short period of time.

## **Parameter Specifications**

### Gyroscope Test

A gyroscope test was conducted to determine some physical characteristics of the rocky system. The "Rocky" was hung from its top and swung as a (non-inverted) pendulum to observe its oscillation frequency and effective length.

#### **Natural Frequency**

A standard pendulum oscillates with a natural frequency of  $\sqrt{\frac{g}{l}}$ , where g is acceleration due to gravity and l is the length of the pendulum. Our team determined the period of oscillation of Rocky as if it were a standard pendulum by observing how much time elapsed between each oscillation, represented by the elapsed time from the local maxima on a graph of angle versus time.

The value of  $\omega_n$ , or natural frequency, is the mean of the elapsed times between each peak, or 4.4142 rad/s




Figure 1: Angle over Time for an Oscillating Rocky

This is the natural frequency at which Rocky oscillates as a normal pendulum.

#### Effective Length

Now that we have the natural frequency of the pendulum, the length can be calculated using  $\omega_n = \sqrt{\frac{g}{l_{eff}}}$ . Since we know  $\omega_n = 4.4142$  rad/s, simplifying the equation reveals that  $l_{eff} = 0.5035$  m, which is almost 20"

#### **Motor Test**

The motor test is designed to determine the characteristics of the motor and inverted pendulum system. This specific test is a step response for Rocky comparing an input motor signal to the output velocity. The characteristics of this motion help determine the motor gain K and time constant  $\tau$ .

#### **Motor Gain**

The motor's gain is the ratio of an input motor signal to an output velocity response. In this test, the input signal has a magnitude of 200 and we must solve for the steady state response.

The input signal is constant, and similar to charging a capacitor, the velocity over time exponentially approaches the steady state response as shown:  $v(t) = -200K(1-e^{-t/\tau})$ . Note that since K is the ratio of the output and input signals, the input signal multiplied by K is the magnitude of the output signal, or velocity. An exponential fit in this form determines the velocity as a function of time to be about  $-200 \cdot (0.0017) \cdot (1-e^{-\frac{t}{0.0611}})$ , shown in Figure 2.

This means that the magnitude of the gain, K is about 0.0017.

#### **Time Constant**

Using the same data as above, we can determine how fast the inverted pendulum approaches the steady state by extracting  $\tau$  from the line of best fit. In this case,  $\tau = 0.0611$  s.




Figure 2: Velocity over Time with a Stepper Input